



GUIDELINES FOR LAYING EASYBAC

PLEASE NOTE BEFORE CUTTING

ALL CARPET TO BE THOROUGHLY INSPECTED BEFORE CUTTING OR INSTALLATION TO INSURE THE CORRECT QUALITY, STYLE AND COLOUR HAVE BEEN RECEIVED AS ONCE YOU HAVE CUT IT YOU OWN IT

- SUBFLOOR AND ALL OTHER PREPARATIONS ARE TO BE IN ACCORDANCE WITH AUSTRALIAN STANDARDS – AS/NZS 2455.1.2007 TEXTILE FLOOR COVERING INSTALLATION PRACTICE.
- JOINS MUST BE SEAM SEALED.
- WHEN USING HEAT BOND IRONS REFER TO THE MANUFACTURERS HEAT SETTINGS.
- DOWNWARD PRESSURE NEEDS TO BE APPLIED TO THE JOIN AS IT IS BEING COMPLETED, TIMBER IS IDEAL AS IT LESSONS HEAT TRANSFER.
- CARPET JOINS NEED SUFFICIENT TIME TO COOL BEFORE TENSIONING, 10 TO 15 MINUTES TIME MAY VARY DUE TO ENVIRONMENTAL CONDITIONS. THE JOIN SHOULD FEEL COOL TO THE BACK OF THE HAND.
- CARPET SHOULD BE STRETCHED IN ACCORDANCE WITH AUSTRALIAN STANDARDS – AS/NZS 2455.1.2007 TEXTILE FLOOR COVERING INSTALLATION PRACTICE.
- **AS EASYBAC IS OF NON WOVEN CONSTRUCTION THE CARPET SHOULD BE STRETCHED UNTIL TAUT AND STARTS TO LIFT FROM THE UNDERLAY IN THE CENTRE OF EACH RUN.**
- CARPETS WITH EASYBAC, WHEN TESTED, HAVE THE SAME DIMENSIONAL STABILITY AS OTHER CARPETS WITH OUTDATED BACKING TYPES BUT WHEN INSTALLED CORRECTLY WILL DELIVER SUPERIOR PERFORMANCE.