

Easybac[®] Laying Guidelines

Please Note Before Cutting

All carpet is to be thoroughly inspected before cutting or installation to ensure the correct quality, style and colour have been received.

Once you have cut it, you own it.

- Subfloor and all other preparations are to be in accordance with Australian Standards – AS/NZS 2455 Textile Floor Covering Installation Practice.
- All joins must be seam sealed.
- It is recommended that carpet in commercial installations should be installed using either the dual bond or direct stick methods of installation.
- When using heat bond irons refer to the manufacturers' heat settings. Beaulieu Australia recommends a low heat setting.
- Downward pressure needs to be applied to the join as it is being completed, timber is ideal as it minimizes heat transfer.
- Carpet joins need sufficient time to cool before tensioning, 10 to 15 minutes. Time may vary due to environmental conditions. The join should feel cool to the back of the hand prior to tensioning.
- Carpet should be stretched in accordance with Australian Standards – AS/NZS 2455 Textile Floor Covering Installation Practice.
- Carpets with Easybac[®], when tested, have the same dimensional stability as other carpets with outdated backing types however when installed correctly, will deliver superior performance.